

※ トラックの燃料タンクに注入する場合は、料理用の計量カップが使いやすいです。

1/5,000 注 入 表

ℓ \ 率	1/5,000 (cc)	ℓ \ 率	1/5,000 (cc)	ℓ \ 率	1/5,000 (cc)	ℓ \ 率	1/5,000 (cc)
10	2	310	62	610	122	1,000	200
20	4	320	64	620	124	2,000	400
30	6	330	66	630	126	3,000	600
40	8	340	68	640	128	4,000	800
50	10	350	70	650	130	5,000	1,000
60	12	360	72	660	132	6,000	1,200
70	14	370	74	670	134	7,000	1,400
80	16	380	76	680	136	8,000	1,600
90	18	390	78	690	138	9,000	1,800
100	20	400	80	700	140	10,000	2,000
110	22	410	82	710	142	11,000	2,200
120	24	420	84	720	144	12,000	2,400
130	26	430	86	730	146	13,000	2,600
140	28	440	88	740	148	14,000	2,800
150	30	450	90	750	150	15,000	3,000
160	32	460	92	760	152	16,000	3,200
170	34	470	94	770	154	17,000	3,400
180	36	480	96	780	156	18,000	3,600
190	38	490	98	790	158	19,000	3,800
200	40	500	100	800	160	20,000	4,000
210	42	510	102	810	162	21,000	4,200
220	44	520	104	820	164	22,000	4,400
230	46	530	106	830	166	23,000	4,600
240	48	540	108	840	168	24,000	4,800
250	50	550	110	850	170	25,000	5,000
260	52	560	112	860	172	26,000	5,200
270	54	570	114	870	174	27,000	5,400
280	56	580	116	880	176	28,000	5,600
290	58	590	118	890	178	29,000	5,800
300	60	600	120	900	180	30,000	6,000

(例) 表から1500ℓの燃料を給油した場合は、200+100=300 で本品を300cc投入する。

計算式: $1500 \div 5 = 300(\text{cc})$